









# Genuine Spare Parts

---




21











12


(x 2)





Utgåva Issue		Bildnr Picture No		VILLA MONTERINGSDETALJER		VILLA ASSEMBLY PARTS		Sida Page	
2008- 11		2196A						274	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717	2718	2719						
1	1				9595-0262-00	Spännstift .....	Locating pin .....		
2A	1				9699-0103-02	Shims .....	Flat washer .....		0.5 mm
2B	1				9699-0114-02	Shims .....	Flat washer .....		1.0 mm
3	2				1134-4185-01	Ansatsbricka .....	Flange washer .....		
5	4				9699-0056-02	Planbricka .....	Flat washer .....		
6	2				1134-4481-01	Vingmutter .....	Wing nut .....		
7	1				1134-4627-01	Dragögla .....	Tow bar .....		
8	2				9959-0820-16	Skruv .....	Screw .....		
9	4				9997-0820-16	Skruv .....	Screw .....		
10A	1				1134-4734-01	Tändningsnyckel .....	Ignition key .....		
10B	1				1134-6125-01	Tändningsnyckel .....	Ignition key .....		
11	1				1134-5245-01	Batterirem .....	Battery strap .....		
12	1				1134-6113-01	Batteriskruvar .....	Battery screws .....		
13	2				9898-1035-16	Skruv .....	Screw .....		
14	2				9739-1031-22	Mutter .....	Nut .....		
X 21	1				8211-0011-80	Bruksanvisning .....	Owner's manual .....		
X 21	1				8211-0012-80	Bruksanvisning .....	Owner's manual .....		
X 21	1				8211-0603-80	Monteringsanvisning .....	Assy instructions .....		
X 21	1				8211-0701-80	Säkerhetsföreskrifter .....	Safety regulations .....		
X 21	1				8211-0950-80	Garantikort .....	Warranty card .....		



Utgåva Issue 2008- 11		Bildnr Picture No 2197		VILLA KAROSS		VILLA BODY WORK		Sida Page 276	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2717	2718	2719						
1	1	1	1	1134-5283-02	Motorhuv- gul .....	Engine hood- yellow .....			
2	7	7	7	9838-9530-12	Skruv .....	Screw .....			
3	1	1	1	1134-5284-02	Motorlucka- grå .....	Engine cover- grey .....			
4	1	1	1	1134-5307-01	Stänkskärm- vä, grå .....	Mud guard- LH, grey .....			
5	1	1	1	1134-5307-02	Stänkskärm- hö, grå .....	Mud guard- RH, grey .....			
6	2	2	2	1134-0225-00	Stödplåt .....	Support plate .....			
7	4	4	4	9699-0056-02	Planbricka .....	Flat washer .....			
8	6	6	6	9945-0816-16	Skruv .....	Screw .....			
9	4	4	4	1134-4176-01	Clips .....	Clips .....			
10	4	4	4	9893-0616-16	Skruv .....	Screw .....			
11	1	1	1	1134-5306-01	Stötfångare, front- vä .....	Bumper, front- LH .....			
12	1	1	1	1134-5306-02	Stötfångare, front- hö .....	Bumper, front- RH .....			
13	1	1	1	1134-5305-01	Front- nedre .....	Front plate- lower .....			
14	6	6	6	9893-0616-16	Skruv .....	Screw .....			
15A	1			1134-5304-01	Front- övre .....	Front- upper .....			
15B		1		1134-5320-02	Front- övre .....	Front- upper .....			
15C			1	1134-5320-05	Front- övre .....	Front- upper .....			
16	2	2	2	9946-0525-16	Skruv .....	Screw .....			
17	2	2	2	1134-4790-02	Styrning .....	Hood guide .....			
18	2	2	2	9838-9530-12	Skruv .....	Screw .....			
19	2	2	2	9699-0060-02	Planbricka .....	Flat washer .....			
20			1	1134-6199-01	Deflektor .....	Deflector .....			
99	1			1134-6426-01	Dekalsats .....	Label kit .....		Villa 12	
99		1		1134-6426-02	Dekalsats .....	Label kit .....		Villa 14 HST	
99			1	1134-6426-03	Dekalsats .....	Label kit .....		Villa 16 HST	






Utgåva Issue		Bildnr Picture No		VILLA RAM		VILLA FRAME		Sida Page	
2008- 11		1642A						278	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2717	2718 2719							
1	1	1		1134-5546-02	Ram.....	Frame.....			
2	1	1		1134-5293-01	Durk.....	Floor plate.....			
3	2	2		9893-0616-16	Skruv.....	Screw.....			
4	1			1134-5338-01	Durkmatta.....	Floor mat.....			
4		1		1134-5339-01	Durkmatta.....	Floor mat.....			
5	1	1		1134-5453-03	Stötfångare- bak, grå.....	Bumper- rear, grey.....			
6	1	1		1134-5334-01	Stag- vä.....	Attachment- LH.....			
7	1	1		1134-5334-02	Stag- hö.....	Attachment- RH.....			
8	2	2		1134-0240-00	Ansatssskruv.....	Shoulder screw.....			
9	2	2		1134-4242-01	Distansbricka.....	Spacer washer.....			
10	2	2		9694-0001-00	Fjäderbricka.....	Washer.....			
11	2	2		9747-0831-02	Mutter.....	Lock nut.....			
12	2	2		9943-0516-16	Skruv.....	Screw.....			
13	2	2		9959-0820-16	Skruv.....	Screw.....		L = 20 mm	
14	2	2		9959-0825-16	Skruv.....	Screw.....		L = 25 mm	
15	1	1		9739-0831-22	Mutter.....	Nut.....			
16	3	3		9739-0831-22	Mutter.....	Nut.....			








Utgåva Issue		Bildnr Picture No		VILLA REDSKAPSLYFT		VILLA LIFTING DEVICE		Sida Page	
2008- 11		1151C						280	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717	2718	2719						
1	1				1134-4117-01 Fäste .....	Bracket .....			
2	2				9959-1025-16 Skruv .....	Screw .....			
3	2				9739-1031-22 Mutter .....	Nut .....			
4	2				1134-2684-01 Lager .....	Bearing .....			
5	1				1134-4945-01 Lyftspärr kpl .....	Lift catch assy .....			
9	1				9404-0027-01 • O-ring .....	• O-ring .....			
10	1				9650-0039-04 • Seegersäkring .....	• Lock ring .....			
11	1				9595-0276-01 • Spännstift .....	• Locating pin .....			
12	1				9997-0640-12 • Skruv .....	• Screw .....			
13	1				9747-0631-02 • Låsmutter .....	• Lock nut .....			
15	1				9897-0820-16 • Skruv .....	• Screw .....			
16	1				9747-0831-02 Mutter .....	Lock nut .....			
17	1				1134-4860-01 Lyftgaffel .....	Lift fork .....			
18	2				1134-0240-00 Ansätsskruv .....	Shoulder screw .....			
19	1				1134-4938-01 Lyftpedal .....	Lift pedal .....			
20	2				9997-0625-16 Skruv .....	Screw .....			
21	2				9739-0631-22 Mutter .....	Nut .....			
22	1				4231-0013-00 Fjäder .....	Spring .....			




Utgåva Issue		Bildnr Picture No		VILLA SITS		VILLA SEAT		Sida Page	
2008- 11		2198						282	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2717	2718 2719							
1	1			1134-5506-01	Sits .....	Seat.....			
2		1		1134-6444-01	Sits .....	Seat.....			
3	1	1		1134-5301-01	Sitsplatta .....	Seat plate .....			
4	2	2		1134-0240-00	Ansatssskruv.....	Shoulder screw.....			
5	2	2		9747-0831-02	Mutter.....	Lock nut.....			
6	1	1		1134-5454-01	Spärr .....	Catch.....			
7	1	1		9675-0012-02	Starlock .....	Locking washer.....			
12	1	1		1134-5296-04	Sitskonsol- gul.....	Seat bracket- yellow .....			
13	1	1		1134-4256-01	Sitsfjäder .....	Seat spring.....			
14	1	1		9924-1235-19	Skruv.....	Screw.....			
15	1	1		9747-1231-02	Låsmutter .....	Lock nut.....			
16	1	1		9997-0840-16	Skruv.....	Screw.....			
17	1	1		1134-1565-06	Distans .....	Spacer .....			
18	1	1		1134-5302-01	Fjäder.....	Spring .....			
19	1	1		1134-5299-01	Tryckplatta.....	Push plate .....			
20	1	1		9699-0090-02	Planbricka.....	Flat washer.....			
21	1	1		9747-0831-02	Mutter.....	Lock nut.....			
22	1	1		1134-3156-02	Brytare (grå).....	Switch (grey) .....			
28	4	3		9959-0820-16	Skruv.....	Screw.....		L = 20 mm	
29	2	1		9959-0825-16	Skruv.....	Screw.....		L = 25 mm	
30	2			9699-0056-02	Planbricka.....	Flat washer.....			
31	6	4		9739-0831-22	Mutter.....	Nut .....			
32		2		9897-0820-16	Skruv.....	Screw.....			
33		2		9757-0821-02	Hattmutter .....	Cap nut .....			
34		2		9699-0090-02	Planbricka.....	Flat washer.....			




51



Utgåva Issue		Bildnr Picture No		VILLA STYRNING	VILLA STEERING	Sida Page		
2008- 11		2199				284		
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717	2718 2719						
X	1	3	3	1134-0041-01	Linhjulshylsa .....	Bushing .....		
	2	3	3	1134-0046-00	Linhållare .....	Wire clamp .....		
	3	1	1	1134-9025-01	Linhjul- sats .....	Steering pulley- kit .....		Sats 2 st/kit of 2
	4	3	3	9997-1040-16	Skruv .....	Screw .....		
	5	2	2	9739-1031-22	Mutter .....	Nut .....		
	6	1	1	1134-2032-04	Styrwire .....	Steering cable .....		
	7	1	1	1134-1310-01	Tryckfjäder .....	Compression spring .....		
	8	1	1	9699-0056-02	Planbricka .....	Flat washer .....		
	9	1	1	9747-0831-02	Mutter .....	Lock nut .....		
	10	1	1	9959-0820-16	Skruv .....	Screw .....		
	11	1	1	1134-5349-03	Styrkonsol- grå .....	Steering console- grey .....		
	12	4	4	9897-0820-16	Skruv .....	Screw .....		
	13	4	4	9739-0831-22	Mutter .....	Nut .....		
	15	1	1	1134-1305-05	Rattrör- nedre .....	Steering column- lower .....		
	16	2	2	1134-1901-01	Lager .....	Bearing .....		
	17	2	2	9893-0616-16	Skruv .....	Screw .....		
	18	2	2	9699-0060-02	Planbricka .....	Flat washer .....		
	19	1	1	1134-5495-01	Rattstång .....	Steering rod .....		
	20	1	1	1134-1933-01	Styrrulle .....	Steering pulley .....		
	21	1	1	9595-0262-00	Spännstift .....	Locating pin .....		
	22	1	1	1134-5496-01	Ratt .....	Steering wheel .....		
	32	1	1	1134-3047-01	Distans .....	Spacer .....		
	33	2	2	9699-0104-02	Bricka .....	Washer .....		
	36	2	2	1134-3047-01	Distans .....	Spacer .....		
	37	1	1	1134-0041-05	Hylsa .....	Bushing .....		
X	38	1	1	1134-0046-00	Linhållare .....	Wire clamp .....		
	39	1	1	1134-9025-01	Linhjul- sats .....	Steering pulley- kit .....		Sats 2 st/kit of 2
	40	1	1	9997-1060-12	Skruv .....	Screw .....		
	50		1	1134-6330-02	Ratt .....	Steering wheel .....		
	51		1	1134-3769-01	• Styrknopp kpl .....	• Steering wheel button .....		
	52		1	1134-3752-01	• Knoppfäste .....	• Knob holder .....		
	53		1	9997-0870-16	• Skruv .....	• Screw .....		
	54		1	1134-1565-06	• Distans .....	• Spacer .....		
	55		3	9699-0090-02	• Planbricka .....	• Flat washer .....		
	56		1	9747-0831-02	• Mutter .....	• Lock nut .....		
	57		1	9403-0043-70	• Plugg .....	• Plug .....		
	58		1	9403-0113-00	• Mutterhatt .....	• Nut cap .....		
	60		1	1134-5216-02	Rattrör- inre .....	Steering tube- inner .....		
	61		1	1134-5177-01	• Slid .....	• Slide .....		
	62		1	9710-0631-12	• Fyrkantmutter .....	• Square nut .....		
	63		1	1134-4481-02	Vingmutter .....	Wing nut .....		
	64		1	9997-0630-12	Skruv .....	Screw .....		




Utgåva Issue		Bildnr Picture No		VILLA HANDREGLAGE		VILLA HAND CONTROLS		Sida Page	
2008- 11		1654A						286	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717								
1	1				1134-5286-01	Reglagepanel- vä .....	Control panel- LH .....		
2	2				1134-5531-01	Dämpare .....	Absorber .....		
3	3				9893-0616-16	Skruv .....	Screw .....		
4	1				1134-5357-01	Fäste .....	Bracket .....		
5	2				9838-9516-12	Skruv .....	Screw .....		
6	1				1134-4077-01	Gasreglage .....	Throttle control .....		
7	1				1134-4078-01	Knopp .....	Knob .....		
8	1				1134-0240-00	Ansatssskruv .....	Shoulder screw .....		
9	1				9694-0001-00	Fjäderbricka .....	Washer .....		
10	2				1134-4242-01	Distansbricka .....	Spacer washer .....		
11	1				9747-0831-02	Mutter .....	Lock nut .....		
12	1				1134-1597-13	Gaswire .....	Throttle cable .....		
13	1				9500-9991-00	Wireklämma .....	Cable clamp .....		
14	1				9943-0516-16	Skruv .....	Screw .....		
15	1				9579-0003-00	Buntband .....	Cable holder .....		
20	1				9997-0812-02	Skruv .....	Screw .....		
21	1				1134-5274-02	Distans .....	Spacer .....		
22	3				1134-3047-01	Distans .....	Spacer .....		
23	1				1134-5271-01	Reglagefäste .....	Control bracket .....		
24	1				1134-5275-01	Växelspak .....	Gear shift lever .....		
25	1				1134-5535-01	Fjäder .....	Spring .....		
26	1				9997-0890-12	Skruv .....	Screw .....		
27	1				9747-0831-02	Mutter .....	Lock nut .....		
28	1				1134-5268-01	Stag .....	Shifter rod .....		
29	1				9675-0009-02	Starlock .....	Starlock .....		
30	1				1134-5271-01	Reglagefäste .....	Control bracket .....		
31	1				1134-5276-01	Reglagespak .....	Control lever .....		
32	1				9997-0890-12	Skruv .....	Screw .....		
33	1				9747-0831-02	Mutter .....	Lock nut .....		
34	1				1134-5356-01	Stag .....	Strut .....		
35	1				9747-0831-02	Mutter .....	Lock nut .....		
36	2				9400-0312-01	Mikrobrytare .....	Micro switch .....		
37	4				9840-7716-16	Skruv .....	Screw .....		
38	1				1134-5358-01	Brytarfäste .....	Switch bracket .....		
39	2				9943-0516-16	Skruv .....	Screw .....		
40	1				1134-5285-01	Reglagepanel- hö .....	Control panel- RH .....		
41	2				1134-5531-01	Dämpare .....	Absorber .....		
42	4				9893-0616-16	Skruv .....	Screw .....		
43	2				1134-2551-01	Reglageknopp .....	Knob .....		
44	1				1134-3573-06	Krafttuttagswire .....	PTO cable .....		
45	1				1134-1242-02	Fjäder .....	Spring .....		
50	1				1134-4093-01	Tändningslås .....	Ignition switch .....		
51	1				1134-4749-01	Mutter .....	Nut .....		






Utgåva Issue 2008- 11		Bildnr Picture No 2201		VILLA HST HANDREGLAGE		VILLA HST HAND CONTROLS		Sida Page 288	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2718								
1	1				1134-5286-04	Reglagepanel- vä .....	Control panel- LH .....		
2	2				1134-5531-01	Dämpare .....	Absorber .....		
3	3				9893-0616-16	Skruv .....	Screw .....		
4	1				1134-5464-01	Fäste .....	Bracket .....		
6	1				1134-5465-01	Gasreglage .....	Throttle lever .....		
7	1				1134-4078-01	Knopp .....	Knob .....		
8	1				1134-0240-00	Ansattsskruv .....	Shoulder screw .....		
9	1				9694-0001-00	Fjäderbricka .....	Washer .....		
10	2				1134-4242-01	Distansbricka .....	Spacer washer .....		
11	1				9747-0831-02	Mutter .....	Lock nut .....		
12	1				1134-4197-03	Gaswire .....	Throttle cable .....		
13	1				9500-9991-00	Wireklämma .....	Cable clamp .....		
14	1				9943-0516-16	Skruv .....	Screw .....		
16	1				1134-6370-01	Wirestyrning .....	Wire guide .....		
19	1				1134-5508-01	Reglagehylsa .....	Control sleeve .....		
20	1				9997-0812-02	Skruv .....	Screw .....		
21	1				1134-5274-02	Distans .....	Spacer .....		
22	1				1134-3047-01	Distans .....	Spacer .....		
30	1				1134-5271-01	Reglagefäste .....	Control bracket .....		
31	1				1134-5276-01	Reglagespak .....	Control lever .....		
32	1				9997-0890-12	Skruv .....	Screw .....		
33	1				9747-0831-02	Mutter .....	Lock nut .....		
34	1				1134-5356-01	Stag .....	Strut .....		
35	1				9747-0831-02	Mutter .....	Lock nut .....		
36	1				9400-0312-01	Mikrobrytare .....	Micro switch .....		
37	2				9840-7716-16	Skruv .....	Screw .....		
40	1				1134-5285-02	Reglagepanel- hö .....	Control panel- RH .....		
41	2				1134-5531-01	Dämpare .....	Absorber .....		
42	4				9893-0616-16	Skruv .....	Screw .....		
43	1				1134-2551-01	Reglageknopp .....	Knob .....		
44	1				1134-3573-06	Kraftuttagwire .....	PTO cable .....		
45	1				1134-1242-02	Fjäder .....	Spring .....		




Utgåva Issue 2008- 11		Bildnr Picture No 1644B		VILLA FOTREGLAGE		VILLA FOOT CONTROLS		Sida Page 290	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717								
1	1				1134-4802-01	Pedal .....	Pedal .....		
2	2				1134-4624-01	Lager .....	Bearing .....		
3	4				9897-0640-12	Skruv .....	Screw .....		
4	4				9739-0631-22	Mutter .....	Nut .....		
5	1				1134-4795-01	Kopplingsstång .....	Clutch rod .....		
6	1				1134-2138-01	Skruvögla .....	Eye bolt .....		
7	1				9739-1031-22	Mutter .....	Nut .....		
8	1				9731-1031-22	Mutter .....	Nut .....		
9	1				9739-0831-22	Mutter .....	Nut .....		
10	1				9747-0831-02	Mutter .....	Lock nut .....		
11	1				9595-0208-00	Spännstift .....	Locating pin .....		
14	1				1134-4777-01	Bromsstag .....	Brake rod .....		
15	1				1134-4617-01	Fjäder .....	Spring .....		
16	2				1134-2138-01	Skruvögla .....	Eye bolt .....		
17	2				9699-0035-02	Planbricka .....	Flat washer .....		
18	4				9595-0208-00	Spännstift .....	Locating pin .....		
19	2				9739-0831-22	Mutter .....	Nut .....		
20	1				9747-0831-02	Mutter .....	Lock nut .....		
26	1				1134-5353-01	Bromsstång .....	Brake rod .....		
27	1				1134-2786-01	Plastknopp .....	Plastic knob .....		
28	1				1131-1497-01	Fjäder .....	Spring .....		
29	1				1134-4002-01	Fäste .....	Brake rod attachment .....		
30	3				9838-9516-12	Skruv .....	Screw .....		
31	1				1134-4714-01	Fästvinkel .....	Angle bracket .....		
32	2				9959-0820-16	Skruv .....	Screw .....		
33	2				9739-0831-22	Mutter .....	Nut .....		
34	1				1134-4715-01	Triangel .....	Triangular plate .....		
35	1				1134-0240-00	Ansattsskruv .....	Shoulder screw .....		
36	1				9694-0001-00	Fjäderbricka .....	Washer .....		
37	1				9699-0036-02	Planbricka .....	Flat washer .....		
38	1				9747-0831-02	Mutter .....	Lock nut .....		
39	1				1134-4717-02	Gångstång .....	Threaded rod .....		
40	2				9570-0004-00	Vinkellänk .....	Elbow link .....		
41	2				9747-0631-02	Låsmutter .....	Lock nut .....		
42	2				9739-0631-22	Mutter .....	Nut .....		
43	1				1134-5279-01	Växelarm .....	Shift lever .....		
43	1				1134-6351-01	Växelarm .....	Shift lever .....		
44	1				9987-5016-16	Skruv .....	Screw .....		
45	1				9699-0060-02	Planbricka .....	Flat washer .....		
46	1				9675-0009-02	Starlock .....	Starlock .....		
51	1				1134-4793-01	Stopplåt .....	Stop plate .....		
52	1				4231-0013-00	Fjäder .....	Spring .....		
53	2				1134-4779-01	Plastbussning .....	Plastic bushing .....		
58	1				9747-0831-02	Mutter .....	Lock nut .....		



Dana 4360-197  
Dana 6800-7



Utgåva Issue 2008- 11		Bildnr Picture No 1645B		VILLA HST FOTREGLAGE		VILLA HST FOOT CONTROLS		Sida Page 292	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2718								
1	1				1134-4802-01	Pedal .....	Pedal .....		
2	2				1134-4624-01	Lager .....	Bearing.....		
3	4				9897-0640-12	Skruv .....	Screw.....		
4	4				9739-0631-22	Mutter.....	Nut .....		
5	1				1134-4949-01	Kopplingsstång.....	Clutch rod .....		
6	2				1134-2138-01	Skruvögla .....	Eye bolt .....		
7	2				9739-1031-22	Mutter.....	Nut .....		
9	1				9739-0831-22	Mutter.....	Nut .....		
10	1				9747-0831-02	Mutter.....	Lock nut.....		
11	1				9595-0208-00	Spännstift .....	Locating pin .....		
12	2				9699-0035-02	Planbricka.....	Flat washer.....		
13	1				1134-4617-01	Fjäder.....	Spring .....		
15	1				9739-0831-22	Mutter.....	Nut .....		
16	1				9747-0831-02	Mutter.....	Lock nut.....		
18	1				9598-0002-02	Låsnål .....	Pin lock .....		
20	1				1134-5353-01	Bromstång .....	Brake rod .....		
21	1				1134-2786-01	Plastknopp.....	Plastic knob .....		
22	1				1131-1497-01	Fjäder.....	Spring .....		
23	1				1134-4002-01	Fäste.....	Brake rod attachment.....		
24	3				9838-9516-12	Skruv .....	Screw .....		
25	1				1134-6353-01	Drivpedal .....	Drive pedal.....		
26	2				1134-6313-01	Lager .....	Bearing.....		
27	2				1134-2700-01	Fäste.....	Bracket.....		
28	2				9959-0820-16	Skruv .....	Screw.....		
29	2				9739-0831-22	Mutter.....	Nut .....		
30	1				9997-0870-16	Skruv .....	Screw.....		
31	2				9739-0831-22	Mutter.....	Nut .....		
34	1				1134-4440-01	Axel .....	Shaft .....		
35	1				1134-4793-01	Stopplåt .....	Stop plate.....		
36	1				1134-4441-01	Stag .....	Link .....		
37	2				1134-0240-00	Ansatsskruv.....	Shoulder screw.....		
38	2				9694-0001-00	Fjäderbricka .....	Washer.....		
39	2				9747-0831-02	Mutter.....	Lock nut.....		
40	1				1134-5288-01	Reglagestång.....	Control rod.....		
41	2				9675-0012-02	Starlock .....	Locking washer.....		
51	1				4231-0013-00	Fjäder.....	Spring .....		
52	1				1134-4779-01	Plastbusning.....	Plastic bushing .....		
53	1				1134-4972-01	Bromslänk .....	Brake link .....		
54	1				9747-0831-02	Mutter.....	Lock nut.....		
55	1				9997-0820-16	Skruv .....	Screw.....		






Utgåva Issue 2008- 11		Bildnr Picture No 2202A		VILLA ELUTRUSTNING		VILLA EL. EQUIPMENT		Sida Page 294	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2717	2718	2719						
1	1	1	1	1134-4804-01	Batteri.....	Battery .....			
4		1	1	1134-4610-01	Fäste.....	Switch bracket .....			
5		1	1	1134-3399-02	Brytare.....	Switch.....			
6		2	2	9852-8013-16	Skruv.....	Screw.....			
7		3	3	9579-0003-00	Buntband.....	Cable holder.....			
8	1	1	1	1134-2042-02	Kabel- svart.....	Cable- black.....		L = 350 mm	
9	1	1	1	9838-9516-12	Skruv.....	Screw .....			
10	1	1	1	9747-0831-02	Mutter.....	Lock nut.....			
11	1	1	1	9795-3531-02	Mutter.....	Nut.....		1/4 UNC	
12	3	3	3	9579-0003-00	Buntband.....	Cable holder.....			
22	1	1	1	9699-0060-02	Planbricka.....	Flat washer.....			
26	1	1	1	1134-2962-01	Solenoid kpl.....	Solenoid assy.....			
27	2	2	2	9794-5131-02	• Mutter.....	• Nut.....			
28	1	1	1	1134-0234-02	Batterikabel ( + ).....	Battery cable ( + ).....		L = 395 mm	
29	1	1	1	1134-2310-01	Batteriskydd.....	Guard cap .....			
30	1	1	1	1134-4702-02	Kabel- röd.....	Cable- red.....		L = 480 mm	
32		1	1	1134-6308-01	Kablage.....	Harness.....			
X 32	1			1134-7218-01	Kablage.....	Harness.....			
32A	1	1	1	1134-3496-06	• Säkring.....	• Fuse .....		20A	
39		1		1134-6348-01	Kablage.....	Harness.....			
39			1	1134-6442-01	Kablage.....	Harness.....			
41		1	1	1134-4093-01	Tändningslås.....	Ignition switch .....			
42		1	1	1134-4749-01	Mutter.....	Nut.....			
43B			1	1134-6291-01	Honkontakt.....	Female terminal.....			
48			1	9400-0282-01	Brytare m.diod.....	Switch w.diode.....			
49			1	9400-0280-03	Vippa- höjinställning.....	Cover- height adjust.....			









Utgåva Issue		Bildnr Picture No		VILLA MOTOR		VILLA ENGINE		Sida Page	
2008- 11		2200						296	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2717 2718	2719							
1	4	4		9997-0840-16	Skruv.....	Screw.....		L = 460 mm	
2	4	4		9747-0831-02	Mutter.....	Lock nut.....			
5	1	1		1134-5266-01	Bränsletank.....	Fuel tank.....			
6	1	1		1134-5532-01	Tanklock.....	Fuel tank cap.....			
7	1	1		1134-3224-01	Bensinkran.....	Fuel shut-off valve.....			
8	1	1		1134-3225-01	Gummibussning.....	Grommet.....			
9	1	1		1134-2975-05	Bensinslang.....	Fuel hose.....			
10	2	2		9578-0023-02	Slangklämma.....	Hose clamp.....			
12	1	1		1134-4808-01	Tankbygel.....	Tank clamp.....			
13	1	1		9699-0060-02	Planbricka.....	Flat washer.....			
14	1	1		9747-0631-02	Låsmutter.....	Lock nut.....			
15	1	1		1134-4807-02	Tank/batterihylla.....	Tank/battery shelf.....			
16	4	4		9829-8830-12	Skruv.....	Screw.....			
19	1	1		1134-0433-00	Ljuddämparpackning.....	Muffler gasket.....			
22	2	2		1134-4930-01	Skruv.....	Screw.....			
23A	1			1134-5455-01	Ljuddämpare.....	Muffler.....			
23B		1		1134-5456-01	Ljuddämpare.....	Muffler.....			
24	1	1		9739-0831-22	Mutter.....	Nut.....			
25	1	1		9959-0820-16	Skruv.....	Screw.....			
26	1	1		1134-5457-01	Värmeskydd.....	Heat guard.....			
27	4	4		9893-0616-16	Skruv.....	Screw.....			



Utgåva Issue		Bildnr Picture No		VILLA TRANSMISSION		VILLA TRANSMISSION		Sida Page	
2008- 11		1643A						298	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717								
1	1				1134-4611-01	Motorremskiva .....	Engine belt pulley .....		
4	1				1134-5414-01	Remstyrning .....	Belt guide .....		
5	1				9699-0056-02	Planbricka .....	Flat washer .....		
6	1				1134-4519-01	Spännarm .....	Tension arm .....		
7	1				1134-9091-01	Spännrulle .....	Tension roller .....		
8	1				1134-4614-01	Ansats .....	Shoulder spacer .....		
9	1				9997-1040-16	Skruv .....	Screw .....		
10	1				9699-0035-02	Planbricka .....	Flat washer .....		
11	1				9739-1031-22	Mutter .....	Nut .....		
12	1				1134-9027-02	Spännrulle- grå .....	Tension roller- grey .....		
13	1				1134-1795-01	Rembygel .....	Belt stirrup .....		
14	1				9997-1040-16	Skruv .....	Screw .....		
15	2				9699-0035-02	Planbricka .....	Flat washer .....		
16	1				9739-1031-22	Mutter .....	Nut .....		
17	1				1134-9065-01	Drivrem .....	Drive belt .....		= 9585-0124-01
18	1				1134-1565-08	Distans .....	Spacer .....		
19	1				9997-0870-16	Skruv .....	Screw .....		
20	2				9699-0056-02	Planbricka .....	Flat washer .....		
21	1				9739-0831-22	Mutter .....	Nut .....		
22	1				1134-5214-01	Fjäder .....	Spring .....		
23A	1				1134-5281-01	Transaxel kpl. ....	Transaxle assy. ....		Dana 4360-197
23B	1				1134-6338-01	Transaxel kpl. ....	Transaxle assy. ....		Dana 6800-7
24	4				9960-0860-12	Skruv .....	Screw .....		
25	4				9747-0831-02	Mutter .....	Lock nut .....		
26	1				1134-4687-01	Momentstag .....	Strut .....		
27	1				9945-0816-16	Skruv .....	Screw .....		
28	1				1134-1849-01	Remskiva .....	Belt pulley .....		
30	1				9650-0016-04	Spårring .....	Lock ring .....		
31	1				1134-4707-01	Remstyrning .....	Belt guide .....		
32	1				9942-0820-16	Skruv .....	Screw .....		
41	1				1134-2138-01	Skruvögla .....	Eye bolt .....		
42	1				1134-4779-01	Plastbussning .....	Plastic bushing .....		
43	1				9739-0831-22	Mutter .....	Nut .....		
44	1				9747-0831-02	Mutter .....	Lock nut .....		



Utgåva Issue		Bildnr Picture No		VILLA HST TRANSMISSION	VILLA HST TRANSMISSION	Sida Page			
2008- 11		1157F				300			
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2718								
1	1				1134-4611-01	Motorremskiva .....	Engine belt pulley .....		
4	1				1134-5414-01	Remstyrning .....	Belt guide .....		
5	1				9699-0056-02	Planbricka .....	Flat washer .....		
6	1				1134-4519-01	Spännarm .....	Tension arm .....		
7	1				1134-9091-01	Spännrulle .....	Tension roller .....		
8	1				1134-4614-01	Ansats .....	Shoulder spacer .....		
9	1				9997-1040-16	Skruv .....	Screw .....		
10	1				9699-0035-02	Planbricka .....	Flat washer .....		
11	1				9739-1031-22	Mutter .....	Nut .....		
12	1				1134-9027-02	Spännrulle- grå .....	Tension roller- grey .....		
13	1				1134-1795-01	Rembygel .....	Belt stirrup .....		
14	1				9997-1040-16	Skruv .....	Screw .....		
15	2				9699-0035-02	Planbricka .....	Flat washer .....		
16	1				9739-1031-22	Mutter .....	Nut .....		
17	1				1134-9064-01	Drivrem .....	Drive belt .....		= 9585- 0099- 01
18	1				1134-1565-08	Distans .....	Spacer .....		
19	1				9997-0870-16	Skruv .....	Screw .....		
20	2				9699-0056-02	Planbricka .....	Flat washer .....		
21	1				9739-0831-22	Mutter .....	Nut .....		
22	1				1134-5214-01	Fjäder .....	Spring .....		
23	1				1134-4846-01	Transaxel kpl. ....	Transaxle assy .....		Kanzaki K46AG
24	4				9960-0860-12	Skruv .....	Screw .....		
25	4				9747-0831-02	Mutter .....	Lock nut .....		
26	1				1134-6290-01	Momentstag .....	Strut .....		
27	1				9945-0816-16	Skruv .....	Screw .....		
28	1				9997-0840-16	Skruv .....	Screw .....		
29	1				9747-0831-02	Mutter .....	Lock nut .....		
42	1				1134-5156-01	Dragstång .....	Pull rod .....		
43	1				1134-4014-01	Plastknopp .....	Plastic button .....		
44	1				9675-0009-02	Starlock .....	Starlock .....		
51	1				1134-2138-01	Skruvögla .....	Eye bolt .....		
52	1				1134-4779-01	Plastbussning .....	Plastic bushing .....		
53	1				9739-0831-22	Mutter .....	Nut .....		
54	1				9747-0831-02	Mutter .....	Lock nut .....		
55	1				1134-5319-01	Remstyrning .....	Belt guide .....		
56	1				9699-0056-02	Planbricka .....	Flat washer .....		



Utgåva Issue		Bildnr Picture No		VILLA HJUL	VILLA WHEELS	Sida Page			
2008- 11		1646B				302			
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717	2718	2719						
1	1				1134-5894-01 Bakaxel .....	Rear axle .....			
2	2				9501-0500-00 Smörjnippel .....	Grease joint .....			
3	1				1134-5009-02 Spindel- vä .....	Spindle- LH .....			
4	1				1134-5009-01 Spindel- hö .....	Spindle- RH .....			
5	2				9699-0088-02 Planbricka .....	Flat washer .....			
6	2				9650-0020-04 Spårring .....	Circlip .....			
7	1				1134-5316-01 Styrskiva .....	Steering pulley .....			
8	1				1134-5575-01 Distans .....	Spacer .....			
9	1				1134-9024-01 Lager .....	Bearing .....		Sats 4 st/kit of 4	
10	1				9699-0104-02 Bricka .....	Washer .....			
11	1				9997-1680-12 Skruv .....	Screw .....			
12	2				1134-3247-05 Styrstag .....	Tie rod .....			
13A	2				9997-0825-16 Skruv .....	Screw .....		L = 25 mm	
13B	1				9997-0835-12 Skruv .....	Screw .....		L = 35 mm	
14	2				9699-0090-02 Planbricka .....	Flat washer .....			
15	3				9747-0831-02 Mutter .....	Lock nut .....			
16	2				1134-4706-01 Fälg .....	Rim .....			
17	1				1134-9026-01 Lagerbussning .....	Bearing bush kit .....		Sats 4 st/kit of 4	
18	2				9545-0117-00 Däck .....	Tyre .....		13 x 5.00 - 6	
19	2				9545-0500-00 Ventil .....	Valve .....			
20	2				1134-0341-01 Bricka .....	Washer .....			
21	2				9650-0020-04 Spårring .....	Circlip .....			
22	2				1134-4344-01 Navkapsel .....	Hub cap .....			
25	1				9501-0500-00 Smörjnippel .....	Grease joint .....			
26	1				9699-0088-02 Planbricka .....	Flat washer .....			
27	1				9650-0020-04 Spårring .....	Circlip .....			
28	2				1134-5255-01 Fälg .....	Rim .....			
29	2				9545-0126-01 Däck .....	Tyre .....		16 x 6.00 - 8	
30	2				9545-0500-00 Ventil .....	Valve .....			
32	6				9731-1031-22 Mutter .....	Nut .....			
33	2				1134-2471-03 Kil .....	Key .....			
34	2				9653-0001-04 Spårryttare .....	Lock ring .....			
35	2				1134-0341-01 Bricka .....	Washer .....			
36	2				1134-4844-02 Hjulnav .....	Wheel hub .....			
37	2				1134-4845-02 Navhylsa .....	Hub sleeve .....			
38	2				1134-4981-01 Bricka .....	Washer .....			
50	2				1134-6274-01 Redskapsfäste kpl. ....	Attachment assy .....			
51	1				1134-9026-01 • Lagerbussning .....	• Bearing bush kit .....		Sats 4 st/kit of 4	
52	1				9501-0502-00 • Smörjnippel .....	• Grease joint .....			
98					9545-0204-00 Innerslang .....	Inner tube .....		Reservdel/spare part	
99					9545-0203-00 Innerslang .....	Inner tube .....		Reservdel/spare part	





Utgåva Issue 2008- 11		Bildnr Picture No 1512E			VILLA KRAFTUTTAG	VILLA POWER TAKE- OFF	Sida Page 304		
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2717	2718	2719						
1	1			1134- 5046- 01	Motorremskiva .....	Engine belt pulley .....		L = 2 1/2"	
2	1			1134- 5017- 01	Bricka .....	Washer .....			
3	1			9987- 5332- 16	Skruv .....	Screw .....			
4	1			1134- 5058- 01	Remstyrning .....	Belt guide .....			
5	1			1134- 5057- 01	Remstyrning .....	Belt guide .....			
6	1			9600- 0251- 01	Kil .....	Key .....			
7	2			9699- 0056- 02	Planbricka.....	Flat washer.....			
8	1			1134- 4650- 01	Monteringsbygel.....	Pulley bracket .....			
9	2			9945- 0816- 16	Skruv .....	Screw .....			
10	1			1134- 4643- 01	Mellanremskiva kpl.....	Intermediate pulley .....			
11	1			1134- 0051- 12	• Distans .....	• Spacer .....			
12	2			9549- 0019- 00	• Kullager .....	• Ball bearing .....			
14	2			1134- 0052- 00	Lagerdistans .....	Bearing spacer .....			
15	1			9997- 1040- 16	Skruv .....	Screw .....			
16	1			9699- 0035- 02	Planbricka.....	Flat washer.....			
17	1			1134- 9079- 01	Drivrem .....	Drive belt.....	= 9585- 0139- 01		
18	1			1134- 5231- 01	Spännarm .....	Tension arm .....			
19	1			1134- 6329- 01	Spännrulle .....	Tension roller .....			
20	1			1134- 4619- 01	Distans .....	Spacer .....			
21	1			9997- 1060- 12	Skruv .....	Screw .....			
22	1			9731- 1031- 22	Mutter.....	Nut .....			
23	1			1134- 6314- 01	Spännarmsfäste.....	Attachment.....			
24	1			9997- 0640- 12	Skruv .....	Screw .....			
25	1			9747- 0631- 02	Låsmutter .....	Lock nut .....			
26	1			1134- 4619- 01	Distans .....	Spacer .....			
27	1			9930- 1050- 12	Skruv .....	Screw .....			
28	1			9699- 0035- 02	Planbricka.....	Flat washer.....			
29	1			9731- 1031- 22	Mutter.....	Nut .....			
30	1			1134- 4708- 02	Fäste.....	Bracket.....			
31	2			9945- 0816- 16	Skruv .....	Screw .....			
36	1			1131- 1507- 00	Fjäder.....	Spring .....			
40	1			1134- 5037- 01	Bygel .....	Bracket.....			
41	1			1134- 1769- 03	Centrumremskiva kpl.....	Centre pulley assy .....			
42	1			1134- 0051- 09	• Distans .....	• Spacer .....			
43	2			9549- 0019- 00	• Kullager .....	• Ball bearing .....			
44	1			1134- 1839- 02	Mellanaxel .....	Shaft .....			
45	1			9699- 0035- 02	Planbricka.....	Flat washer.....			
46	1			9739- 1031- 22	Mutter.....	Nut .....			
47	1			9997- 1070- 12	Skruv .....	Screw .....			
48	1			1134- 5541- 01	Kopplingsarm .....	Clutch lever .....			
49	1			1134- 1565- 10	Distans .....	Spacer.....			
50	1			9997- 0860- 16	Skruv .....	Screw .....			
51	1			9699- 0056- 02	Planbricka.....	Flat washer.....			
52	1			9739- 0831- 22	Mutter.....	Nut .....			
53	1			1134- 9027- 02	Spännrulle- grå .....	Tension roller- grey .....			
54	1			1134- 1795- 01	Rembygel .....	Belt stirrup .....			
55	1			9997- 1040- 16	Skruv .....	Screw .....			
56	2			9699- 0035- 02	Planbricka.....	Flat washer.....			
57	1			9739- 1031- 22	Mutter.....	Nut .....			
58	1			1134- 9078- 01	Drivrem .....	Drive belt.....	= 9585- 0138- 01		
59	1			1134- 4164- 03	Bromsklots .....	Brake pad .....			
60	1			9959- 0820- 16	Skruv .....	Screw .....			
61	1			9699- 0090- 02	Planbricka.....	Flat washer.....			
62	1			9747- 0831- 02	Mutter.....	Lock nut.....			
63	2			9959- 0820- 16	Skruv .....	Screw .....			
64	2			9739- 0831- 22	Mutter.....	Nut .....			
65	1			9699- 0056- 02	Planbricka.....	Flat washer.....			
66	1			1131- 1506- 00	Fjäder.....	Spring .....			
67	1			9997- 0860- 16	Skruv .....	Screw .....			
68	2			9739- 0831- 22	Mutter.....	Nut .....			